

HDMI Switcher

Model No.:LM-SW09

Operating Instructions



Dear Customer

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

FEATURES

1. 3HDMI inputs,1 HDMI output
2. Compact size
3. Supports data rates up to 2.7Gbps
4. Supports deep color display.
5. Supports Resolution up to1080p
6. No need DC power
7. Easy to install and operate.
8. No need DC power

NOTICE

Our company reserve the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.

TABLE OF CONTENTS

Specifications

Package Contents

Panel Descriptions

Connecting and Operating

Maintenance Product Service Warranty

SPECIFICATIONS


Operating Temperature	-5 to +35 °C (+23 to +95 °F)
Operating Humidity	5 to 90%RH (No Condensation)
Input Video Signal	0.5-1.0 Volts P-P
Input DDC Signal	5 volts p-p(TTL)
Support Video format	DTV/HDTV:1080P/1080i/720P/576P/576i/480P/480i
Support Video Color	xv-YCC/deep color
Support Audio Format	DTS-HD Master Audio, Dolby true-HD
Output Video	HDMI 1.3
Data transfer speed rate	2.7Gbps(Maximum)
Power consumption	4watts(Maximum)
Transmission Distance	5m(Maximum)over standard HDMI
Dimension (L×W×H)	50x50x14mm
Net Weight	28g
Gross Weight	40g
Gift box measurement	L7.5xW7.5xH2.8cm
Master carton	100PCS/CTN

Note: Specifications are subject to change without notice. Mass and dimensions are approximate.

Packing Contents:

- 1) Main Unit. square 3x1 HDMI switcher
- 2) Operating Instructions

PANEL DESCRIPTIONS



1) HDMI output port

2) Input Select Button: Manually select button to switch signal source

3) Indicator of HDMI output. When HDMI ports output signal ,the corresponding LED lights.

4) HDMI input ports

Connecting and Operating

1) Connect the HDMI signal sources(Such as PS3,STB etc) into HDMI input

2) Connect the HDMI display device (such as :HD-LCD,HD-DLP) into HDMI output. Attention: Insert/Extract cable gently.

MAINTENANCE

Clean this unit with a soft, dry cloth. Never use alcohol, paint thinner or benzine to clean this unit.

PRODUCT SERVICE

1) Damage requiring service: The unit should be serviced by qualified service personnel if: (a)The DC power supply cord or AC adaptor has been damaged;

(b)Objects or liquids have gotten into the unit; (c)The unit has been exposed to rain;

(d)The unit does not operate normally or exhibits a marked change in performance; (e)The unit has been dropped or the cabinet damaged.

2) Servicing Personnel: Do not attempt to service the unit beyond that described in these operating instructions. Refer all other servicing to authorized servicing personnel.

3) Replacement parts: When parts need replacing ensure the servicer uses parts specified by the manufacturer or parts that have the same characteristics as the original parts. Unauthorized substitutes may result in fire, electric shock, or other hazards.

4) Safety check: After repairs or service, ask the servicer to perform safety checks to confirm that the unit is in proper working condition.

WARRANTY

If your product does not work properly because of a defect in materials or workmanship, our Company (referred to as "the warrantor") will , for the length of the period indicated as below, (Parts(1)Year ,Labor(90) Days) which starts with the date of original purchase ("Limited Warranty period"), at its option either(a) repair your product with new or refurbished parts, or (b) replace it with a new of a refurbished product. The decision to repair or replace will be made by the warrantor. During the "Labor" Limited Warranty period there will be no charge for labor.

During the "Parts" warranty period, there will be no charge for parts. You must mail-in your product during the warranty period. This Limited Warranty is extended only to the original purchaser and only covers product purchased as new. A purchase receipt or other proof of original purchase date is required for Limited Warranty service.

Mail-In Service

When shipping the unit carefully pack and send it prepaid, adequately insured and preferably in the original carton. Include a letter detailing

the complaint and provide a day time phone and/or email address where you can be reached.

LIMITED WARRANTY LIMITS AND EXCLUSIONS

1) This Limited Warranty **ONLY COVERS** failures due to defects in materials or workmanship, and **DOES NOT COVER** normal wear and tear or cosmetic damage. The Limited Warranty **ALSO DOES NOT COVER** damages which occurred in shipment, or failures which are caused by products not supplied by warrantor, or failures which result from accidents, misuse, abuse, neglect, mishandling,

misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, or service by anyone other than a Factory Service center or other Authorized Servicer, or damage that is attributable to acts of God.

2) **THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY COVERAGE". THE WARRANTOR IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY.** (As examples, this excludes damages for lost time, cost of having someone remove or re-install an installed unit if applicable, travel to and from the service, loss of or damage to media or images, data or other recorded content. The items listed are not exclusive, but are for illustration only.)

3) **PARTS AND SERVICE, WHICH ARE NOT COVERED BY THIS LIMITED WARRANTY, ARE YOUR RESPONSIBILITY.**